

Maior portal de Automação Comercial do Brasil! Encontre o que sua empresa precisa com preços especiais, atendimento especializado, entrega rápida e pagamento facilitado.





Impressora Zebra ZQ220

A Impressora de Etiquetas Portátil Zebra ZQ220 que oferece o equilíbrio perfeito entre custo, qualidade, versatilidade e durabilidade. Quando se trata de versatilidade, esta impressora ofusca a concorrência, permitindo que você imprima diversos tipos e larguras de mídia para atender a todas as suas necessidades de impressão, hoje e no futuro.



ZQ220 Mobile Printer



User Guide



P1102927-001 Rev. A December 2018

Contents

| Proprietary Statements | 5 |
|-------------------------------------|----|
| Document Conventions | 7 |
| Introduction to the ZQ220 Printer | 8 |
| Unpacking and Inspection | 9 |
| Reporting Damage | 9 |
| ZQ220 Technology | 10 |
| Battery | 10 |
| QR Code | 11 |
| Made for iPhone (MFi) | 12 |
| Near Field Communication (NFC) | 12 |
| Printer Overview | 13 |
| Getting Ready to Print | 15 |
| Battery | 15 |
| Removing the Battery | 15 |
| Removing the Battery Tape Insulator | 16 |
| Installing the Battery | 17 |
| Battery Safety | 18 |
| Charger Safety | 18 |
| Charging the Battery | 19 |
| AC-to-USB Charger | 19 |
| Loading Media Procedure | 21 |
| Operator Controls | 23 |
| Standard User Controls | 23 |
| LCD Control Panel | 23 |
| 2 | |

| Information Screen | |
|-------------------------------|------------------|
| Configuration Screen | |
| Buttons | |
| Power-Up Sequences | |
| Verify the Printer is Working | 927 |
| Printing a Configuration Re | port27 |
| Connecting the Printer | |
| Cable Communication | |
| USB Communications | |
| Zebra Setup Utilities | |
| Wireless Communications | with Bluetooth30 |
| Bluetooth Networking Over | view |
| Bluetooth Security Modes. | |
| Bluetooth Minimum Securit | y Modes |
| Setting Up the Software | |
| Designing Labels | |
| Using Pre-Printed Receipt | Media35 |
| Black Mark Dimensions (R | eceipt Media)35 |
| Label Areas | |
| Label Design Examples | |
| Keep-Out Areas | |
| Near Field Communication | (NFC) |
| NFC Use Cases | |
| Wearing the Printer | |
| Swivel Belt Clip | |
| Adjustable Shoulder Strap | 41 |
| Soft Case | |
| Preventive Maintenance | |
| Extending Battery Life | |
| General Cleaning Instruction | ns43 |
| LCD Control Panel Indicate | ors46 |
| Troubleshooting Topics | |
| Troubleshooting Tests | |
| Printing a Configuration La | bel48 |
| Communications Diagnosti | cs48 |
| Specifications | |
| - | |

| Printing Specifications | 52 |
|---|------|
| Memory and Communications Specifications | 52 |
| Label Specifications | 53 |
| Physical, Environmental and Electrical Specifications | 53 |
| CPCL Font and Bar Code Specifications and Commands | 54 |
| Printer Dimensions | 55 |
| Printer Accessories | 56 |
| Appendix A | . 57 |
| USB Cables | 57 |
| Appendix B | . 58 |
| Media Supplies | 58 |
| Appendix C | . 58 |
| Maintenance Supplies | 58 |
| Appendix D | . 59 |
| Appendix E | 60 |
| Battery Disposal | 60 |
| Product Disposal | 60 |
| Appendix F | 61 |
| Alert Messages | 61 |
| Appendix G | . 62 |
| Using Zebra.com | 62 |
| Appendix H | . 64 |
| Product Support | 64 |

Copyright

© **2018 ZIH Corp and/or its affiliates.** All rights reserved. ZEBRA and the stylized Zebra head are trademarks of ZIH Corp., registered in many jurisdictions worldwide. All other trademarks are the property of their respective owners.

Information in this document is subject to change without notice.

For further information regarding legal and proprietary statements, please go to:

COPYRIGHTS AND TRADEMARKS: For complete copyright and trademark information, go to <u>www.zebra.com/copyright</u> WARRANTY: For complete warranty information, go to <u>www.zebra.com/www.zebra.com/www.zebra.com/eula</u> END USER LICENSE AGREEMENT: For complete EULA information, go to <u>www.zebra.com/eula</u>

Terms of Use

Proprietary Statement: This manual contains proprietary information of Zebra Technologies Corporation and its subsidiaries ("Zebra Technologies"). It is intended solely for the information and use of parties operating and maintaining the equipment described herein. Such proprietary information may not be used, reproduced, or disclosed to any other parties for any other purpose without the express, written permission of Zebra Technologies.

Product Improvements: Continuous improvement of products is a policy of Zebra Technologies. All specifications and designs are subject to change without notice. Liability Disclaimer: Zebra Technologies takes steps to ensure that its published Engineering specifications and manuals are correct; however, errors do occur. Zebra Technologies reserves the right to correct any such errors and disclaims liability resulting therefrom.

Liability Disclaimer: Zebra Technologies takes steps to ensure that its published Engineering specifications and manuals are correct; however, errors do occur. Zebra Technologies reserves the right to correct any such errors and disclaims liability resulting therefrom.

Limitation of Liability: In no event shall Zebra Technologies or anyone else involved in the creation, production, or delivery of the accompanying product (including hardware and software) be liable for any damages whatsoever (including, without limitation, consequential damages including loss of business profits, business interruption, or loss of business information) arising out of the use of, the results of use of, or inability to use such product, even if Zebra Technologies has been advised of the possibility of such damages. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

"Made for iPod", "Made for iPhone", and "Made for iPad" mean that an electronic accessory has been designed to connect specifically to iPod, iPhone, or iPad, respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod, iPhone, or iPad may affect wireless performance.

Bluetooth® is a registered trademark of the Bluetooth SIG.

© 1996-2009, QNX Software Systems GmbH & Co. KG. All rights reserved. Published under license by QNX Software Systems Co.

All other brand names, product names, or trademarks belong to their respective holders. ©2018 ZIH Corp.

Works with:



Windows BiPod DiPhone DiPad

Certified by:



Document Conventions

RA

The following graphic icons are used throughout the documentation set. These icons and their associated meanings are described below.



Note • Indicates neutral or positive information that emphasizes or supplements important points of the main text.

This user guide gives you the information you will need to operate the ZQ220 Mobile Printer. The printer uses some of the latest technologies such as USB charging (Type-C connector), an embedded Dual Mode Bluetooth 2.1 + EDR/4.1 Low Energy module, Near Field Communication (NFC) and Made for iPhone® (MFi). MFi printers provide Apple co-processor (MFi) support which allows an Apple device such as an iPhone or iPad® to authenticate and connect over Bluetooth®.



This printer uses CPCL programming language. To create and print labels using this language, refer to the Programming Guide for CPCL (p/n P1073699-001). See "Appendix G" on page 62 for instructions on how to access manuals on zebra.com.

ZQ220 Software Utilities:

- ZebraNet Bridge Enterprise™: printer configuration, fleet management
- · Zebra Setup Utility: single printer configuration, quick setup
- ZebraDesigner Pro v2: label design
- ZebraDesigner Drivers: Windows® driver
- · OPOS Driver: Windows driver
- Legacy SDK (part of Multiplatform SDK that supports limited legacy freatures.)

These utilities can be found on the Zebra website at <u>http://www.zebra.com/support</u>. (See "Appendix G" on page 62.)

Unpacking and Inspection

- Check all exterior surfaces for damage.
- Open the media cover (see "Loading Media Procedure" on page 21) and inspect the media compartment for damage.

In case shipping is required, save the carton and all packing material.



Reporting Damage

If you discover shipping damage:

- Immediately notify and file a damage report with the shipping company. Zebra Technologies Corporation is not responsible for any damage incurred during shipment of the printer and will not cover the repair of this damage under its warranty policy.
- Keep the carton and all packing material for inspection.
- Notify your authorized Zebra re-seller.

ZQ220 Technology

The ZQ220 printer uses several technologies made popular in other Zebra Mobile Printer product lines, as well as newer, state-of-theart technologies.

Battery

The printer uses a 2-cell Li-Ion battery pack (p/n BTRY-MPV-24MA1-01) with a charge time of under four (4) hours using a 10W USB charger or cigarette-to-USB adapter. The battery allows the printers to print reliably without recharge for three (3) work days under the following conditions: 25 stops per day and will power up the device 25 times per day; up to 500 3x8.5 in. receipts per 8-hour shift with 13% coverage.

| Operating Temperature | Charging Temperature | Storage Temperature |
|-----------------------|----------------------|---------------------|
| -10°C to +50°C | 0°C to +40°C | -20°C to +60°C |
| (14°F to 122°F) | (32°F to 104°F) | (-4°F to 140°F) |



The ZQ220 printer will only function properly with genuine Zebra battery packs.



Note • Power down the printer before removing the battery to minimize the risk of corruption.

Printing Technology

The ZQ220 printer uses the Direct Thermal method to print human-readable text, graphics, and barcodes. It incorporates a sophisticated print engine for optimal printing under all operational conditions. Direct thermal printing uses heat to cause a chemical reaction on specially treated media. This reaction creates a dark mark wherever a heated element on the printhead comes in contact with the media. Because the printing elements are arranged very densely at 203 dpi (dots per inch) horizontal and 200 dpi vertical, highly legible characters and graphic elements may be created a row at a time as the media is advanced past the printhead. This technology has the advantage of simplicity, as there is no requirement for consumable supplies such as ink or toner. However, because the media is sensitive to heat, it will gradually lose legibility over long periods of time, especially if exposed to environments with relatively high temperatures or in direct sunlight.

QR Code

The QR barcode includes human readable text URL, for example <u>www.zebra.com/zq220-info</u>, which links the user to printer information and short videos on topics such as buying supplies, features overview, loading media, printing a configuration report, cleaning instructions, and accessory information.



Figure 1 • QR Code

Made for iPhone (MFi)

The ZQ220 printer supports communication with Apple devices running iOS 10 or later over a standalone Bluetooth 4.1 radio.



Near Field Communication (NFC)

The printer supports a passive NFC tag which complies with the "Android Standard Tag format" because Android devices are the most common found on the market today. The NFC tag is programmed from the factory and supports Bluetooth pairing to enable a tablet, smartphone, or terminal to automatically pair with the printer via a Bluetooth connection (within the bounds of the security profile being used).

The NFC tag also supports app launching whereby an app developed either by Zebra or a third party will launch on an NFCenabled smartphone, tablet or terminal. Similarly, the NFC tag enables launching to a web support page via a tablet, smartphone, or terminal.



Figure 2 • Overview of Features

- 1. Platen Roller
- 2. Back Side Sensor
- 3. Front Side Sensor
- 4. Latch Release Lever
- 5. Tear Bar
- 6. USB Port
- 7. Feed Button
- 8. Strap Posts
- 9. Configure Button
- 10. Power Button
- 11. LCD Display
- 12. Printhead
- 13. Media Cover
- 14. Belt Clip
- 15. Battery
- 16. MAC Address Label





Note • Scanning the QR code with a smartphone will provide printer specific information at <u>www.zebra.com/zq220-info</u>.

| | 4 |
|-------------------------|---|
| = | 4 |
| $\mathbf{K} \mathbf{A}$ | 1 |
| | I |

Note • Tapping the Zebra Print Touch[™] icon with a Near Field Communication (NFC) enabled smartphone will provide instant access to printer-specific information. For more information about NFC and Zebra products, go to <u>http://www.zebra.com/nfc</u>. Bluetooth pairing applications via NFC is also possible. See the Zebra Legacy SDK for more information.



Getting Ready to Print

Battery

Installing/Removing Battery & Battery Tape Insulator

Important • Batteries are shipped in sleep mode to preserve their maximum capacity while in storage prior to initial use. Plug in the USB adapter (see "AC-to-USB Charger" on page 19) to wake it up before using for the first time.

Removing the Battery

- If a belt clip is present on the bottom of the printer, rotate it such that it provides clearance for the battery.
- 2. Depress the latch on the battery pack where indicated.





3. Rotate the pack away from the battery well. Lift the battery up and out of the printer.

Removing the Battery Tape Insulator

The battery tape insulator is designed to cover the battery contacts and allow the printer to be shipped with the battery installed.





1. Pull up on the tape insulator tab located on the bottom of the battery pack.

2. Peel back the tape insulator and remove it from the top of the battery pack. Discard upon removal.

Caution • Battery can explode, leak or catch fire if improperly charged or exposed to high temperature. Do not disassemble, crush, puncture, short external contacts or dispose of in fire or water. Charge on a Zebra approved Lithium-Ion charger only.

Installing the Battery

- 1. Locate the battery compartment on the bottom of the printer (where indicated).
- 2. Swivel the belt clip (if present) to access the battery compartment.
- 3. Insert the battery into the printer as shown. (It is not possible to insert the pack in the incorrect orientation.)





4. Rock the battery into the compartment as shown until it locks in place.



Battery Safety

Caution • Avoid accidental short circuiting of any battery. Allowing battery terminals to contact conductive material will create a short circuit which could cause burns and other injuries or could start a fire.



Important • Always refer to the Important Safety Information data sheet shipped with each printer and the Technical Bulletin shipped with each battery pack. These documents detail procedures to ensure maximum reliability and safety while using this printer.

0

Important • Always dispose of used batteries properly. See "Appendix E" on page 60 for more battery recycling information.



Caution • Use of any charger not approved specifically by Zebra for use with its batteries could cause damage to the battery pack or the printer and will void the warranty.

Caution • Do not incinerate, disassemble, short circuit, or expose to temperatures higher than 60°C (140°F).

Charger Safety



Do not place any charger in locations where liquids or metallic objects may be dropped into the charging bays.

AC-to-USB Charger



Important • You must charge the battery fully before using the printer for the first time.



Install the adapter plug into the Power Supply by hooking the top edge into the adapter's receptacle cavity and rotating it until it snaps into place.



Note • Verify that the adapter plug shipped with your Printer is the correct one for your region.



Note • The battery can also be charged using the 3-slot charger, but only after firmware modifications have been made to the charger. See "Printer Accessories" on page 56 for part numbers.



Note • Batteries which have reached partial charge capacity may be used, however, it is recommended that you allow the batteries to reach a full charge to maintain maximum battery life.

- 1. Connect the male end of the AC-to-USB adapter into an appropriate power outlet using the appropriate plug for your region.
- 2. Connect one end of the USB charging cable to the adapter (as shown).
- 3. Rotate the rubber door on the side of the printer to access the USB port.





- 4. Connect the other end of the USB cable to the port on the side of the printer.
- 5. The printer will power-on and begin charging.



Loading Media in the Printer

Loading Media Procedure

Press the Latch Release Lever on the side of the printer as shown in "1" below. The Media Cover will open automatically.

Rotate the Media Cover back completely as shown in "2", exposing the media compartment.







Note • The printers also have the option to use media spacers (*p/n KIT-MPV-MD3SPR1-5*) which are placed in the media compartment and allow the printer to accept 76.2 mm (3 in.), 58 mm (2.3 in.) and 50.8 mm (2 in.) wide paper.

Insert the roll of media (in the orientation shown) in the media compartment. The media roll will be able to spin freely inside the media compartment.





Close the media cover as shown below and the paper will advance through the paper path.







Note • Please refer to the Programming Guide (P1099958-001) for information on changing the setting to adjust the media feed length via a Set-Get-Do (SGD).

Operator Controls

The ZQ220 printer comes equipped with a three-button user interface for menu navigation (see "Figure 6 • Control Panel" on page 23). The printer also features an OLED display which stays lit while the printer is powered on to indicate to the user that the printer is on.

Standard User Controls

The standard controls have three (3) buttons that perform the following user functions.

- The Power Button turns the printer on and off.
- The Media Feed Button advances a length of media which is determined by the type of media being used. Label media will be advanced to the next gap or bar sense marker. Journal (plain) media will be advanced by a length determined by the printer's software. When in Configuration Screen mode, the Feed Button may be used to select a function highlighted on the display.
- The Configuration Button allows the user to scroll between functions on the display.



Figure 6 • Control Panel

Power Button

Press to turn unit on. Printer boots up in approx. 1 second. Press for 5 seconds to turn unit off.

Configuration Button

Press to alter printer parameters, print a configuration report or dismiss an acknowledged message.

Media Feed Button

Press to advance a blank label or a software-determined length of journal media. Press to navigate while in Configuration Screen mode.

LCD Control Panel

The LCD control panel allows the user to view content in one of three modes: *Operation Screen mode*; *Information Screen mode*; and *Configuration Screen mode*. The default mode which the user sees upon powering up the printer is Operation Screen mode. This mode is the display shown when the printer is idle, printing and/or receiving data and has no need to convey information beyond icons shown on the display. The LCD can display up to five (5) status icons, including Status, Media, Data, Bluetooth and Battery.

• Status Icons: Convey the following printer status conditions:

Ready \checkmark : Indicates printer is fully operational. Warning \triangle : Indicates there is a condition the user should be aware of but the printer is still functional. Error \blacksquare : Indicates there is something wrong with the printer

that prevents some basic functionality from being used.

• Media Icon: Conveys information about the printer's media.

Media Present 6: Media is loaded and ready to print. Media Out 8: No media loaded in the printer. Door Open 6: Media cover is unlatched.

- Data lcons:
 - : Printer is not receiving data.
 - Printer is receiving data.
- Bluetooth Icon: Determines the state of the Bluetooth radio. Connected: Disconnected: No icon
- Battery Icon: Displays battery charge status. Battery Level : 0 to 4 bars.

Battery Level while charging 📓 : 0 to 4 bars with lightning bolt. Power from USB 🛐 : Battery with USB icon inside. Battery Low: Battery icon with zero bars. Charge Error **Î** : Battery with error icon inside.

Information Screen

The Information Screen is displayed when text must be used to convey information to the user. The display is split into two viewing areas: The top portion will display the same icons previously described on the Operation Screen; the bottom portion will display text messages. There are two (2) types of messages that can be displayed on the Information Screen as described below.

1. *Timed Messages*: These messages will appear for a specific period of time, and then be removed. For example, after powering up the printer and the printer is ready to print, the message "PRINTER READY" will appear for 30 seconds.



2. User Activity Messages: These messages require that the user performs a needed action. For example, when the printer is out of media, a "MEDIA OUT" message will be displayed until new media is loaded in the printer.



The following User Activity Messages are supported by the printer:

| DOWNLOAD FW | HEAD UNDERTEMP |
|------------------|-----------------|
| DOWNLOAD FAILED | BATTERY TOO LOW |
| PAIRING: 123456 | MEDIA OUT |
| PAIRING ONGOING | HEAD OPEN |
| PAIRING ACCEPTED | CHARGE ERROR |
| PAIRING REJECTED | NO PRINTING |
| PAIRING FAILED | BATTERY LOW |
| PAIRING SUCCESS | PRINTER READY |
| HEAD OVERTEMP | |

When the Information Screen is used to display text messages, it replaces the Operation Screen. When the text message has been acknowledged, the printer will return to the Operation Screen.

Configuration Screen

The Configuration Screen is used as a means to alter printer parameters or initiate printing a configuration label. Specifically, the user will be able to change the following parameters.

- *Darkness*. The user can increase or decrease the darkness by pressing the Media Feed button.
- *Power Up*. The user can select either Feed On or Feed Off by pressing the Media Feed button.
- *Head Close*: The user can select either Feed On or Feed Off by pressing the Media Feed button.
- *Print*: The user can print a configuration report by pressing the Media Feed button.
- *MAC Address*: The user can select either Display On or Display Off by pressing the Media Feed button.
- *Exit Configuration*: The user can exit the Configuration Screen and return to the Operation Screen by pressing the Media Feed button.

Buttons

The user has the ability to use the printer's multi-button interface to run the following power-up and runtime sequences.

| Seq. # | Function | Keys | Button |
|--------|---------------------------|---|----------------|
| 1 | Two Key Report | Hold down Feed button while pressing and releasing the Power Button | 0 * U |
| 2 | Forced Download | Hold down the Configuration and Feed buttons while pressing Power Button | ☆ ○ ≎ Ů |
| 3 | Turn printer On or Off | Power button | С С |

Verify the Printer is Working

Before you connect the printer to your computer or portable data terminal, make sure that the printer is in proper working order. You can do this by printing a configuration label using the "two key" method. If you can't get this label to print, refer to "Troubleshooting Topics" on page 46.

Printing a Configuration Report

- 1. Turn the printer off. Load the media compartment with journal media (media with no black bars or gaps on the back).
- 2. Press and hold the Feed Button.
- 3. Press and release the Power button and keep the Feed button pressed. When printing starts, release the Feed button. The unit will print a line of interlocking "x" characters to ensure all elements of the print head are working, print out the version of software loaded in the printer, and then print the report.

You can also print a configuration report by turning the printer on, pressing the Configuration button multiple times until you get to the SETTINGS-PRINT screen, and then pressing the Media Feed button to print the report.

The report indicates model, serial number, baud rate, and more detailed information on the printer's configuration and parameter settings. (See "Troubleshooting Tests" on page 48 for sample printouts and a further discussion on how to use the configuration label as a diagnostic tool.)

Connecting the Printer

The printer must establish communications with a host terminal which sends the data to be printed. Communications occur in four (4) basic ways:

- Via a cable using USB 2.0 protocols. Windows drivers that support printing via Serial, USB and the network are included in the Zebra Designer Driver which can be downloaded from www.zebra.com/drivers.
- Via Bluetooth short range radio frequency link.
- Via WinMobile[®], Blackberry[®], and Android[®] devices using standard Bluetooth protocol.
- Via Bluetooth to an Apple® iOS device.





Cable Communication



Caution • The printer should be turned off before connecting or disconnecting a communications cable.

The standard cable connection for the printers is a USB 2.0 communication and charging cable. One end of the cable has a USB Type-A connector while the other end is USB Type-C.

USB Communications

The small Type C connector on the USB cable plugs into the printer. The connector is not keyed and therefore can be plugged in in either direction. However, do not try to force the cable if it does not plug in. The Type A end of the cable must be plugged into any USB 2.0 host port. The printers utilize the USB cable to charge the printer (see "AC-to-USB Charger (cont.)" on page 20) and for communications between the printer and computer.





ZebraDesigner Driver uses Windows drivers that support printing via USB and the network. Other terminals or communications

devices may require the installation of special drivers to use the USB connection. Consult the factory for further details.

Zebra Setup Utilities

Before you start to configure your printer for use on a Local Area Network (LAN), you will need some basic information which will enable you to establish the network configuration for your printer. Zebra Setup Utilities (ZSU) provides a quick and easy way to configure your printers for a variety of purposes, including setting them up for wireless communications either on a Local Area Network (LAN) or using the international Bluetooth[™] communications standard.

Once ZSU has been downloaded to your computer, attach the USB cable to the printer and computer as shown in Figure 6. Refer to Wireless Configuration Guide (p/n P1048352-001) to follow the steps necessary for setting up and configuring your printer via ZSU.

Go to <u>https://www.zebra.com/us/en/support-downloads.html</u> to download ZSU and the Wireless Configuration Guide. (See "Appendix G" on page 62 for details on navigating zebra.com.)

Wireless Communications with Bluetooth

Bluetooth is a worldwide standard for the exchange of data between two devices via radio frequencies. This form of pointto-point communication does not require access points or other infrastructure. Bluetooth radios are relatively low powered to help prevent interference with other devices running at similar radio frequencies. This limits the range of a Bluetooth device to about 10 meters (32 feet). The default for the printers is Class 2. Both the printer and the device it communicates with must follow the Bluetooth standard.

Bluetooth Networking Overview

Each Bluetooth enabled printer is identified by a unique Bluetooth Device Address (BDADDR). This address resembles a MAC address whereby the first three bytes are vendor, and the last three bytes are device (e.g. 00:22:58:3C:B8:CB). This address is labeled on the back of the printer via a barcode for ease of pairing (see "Figure 8 • BT Communications" on page 33). In order to exchange data, two Bluetooth enabled devices must establish a connection. Bluetooth software is always running in the background, ready to respond to connection requests. One device (known as the client) must request/initiate a connection with another. The second device (the server) then accepts or rejects the connection. A Bluetooth enabled printer will normally act as a slave creating a miniature network with the terminal sometimes referred to as a "piconet". Discovery identifies Bluetooth devices that are available for pairing whereby the master device broadcasts a discovery request and devices respond. If a device is not discoverable, the master cannot pair unless it knows the BDADDR or has previously paired with the device. If both devices support Bluetooth 2.1 or higher they will use Security Level 4 Secure Simple Pairing (SSP), a mandatory security architecture that features two (2) association models: Numeric Comparison and Just Works (no user confirmation).

Bluetooth Security Modes

Security Mode 1

If a BT>/= 2.1 device is pairing with a BT</= 2.0 device, it falls back to BT 2.0 compatibility mode and behaves the same as BT 2.0. If both devices are BT >/= 2.1, Secure Simple Pairing must be used according to the BT spec.

Security Mode 2

If a BT >/= 2.1 device is pairing with a BT </= 2.0 device, it falls back to BT 2.0 compatibility mode and behaves the same as BT 2.0. If both devices are BT >/= 2.1, Secure Simple Pairing must be used according to the BT spec.

Security Mode 3

If a BT >/= 2.1 device is pairing with a BT </= 2.0 device, it falls back to BT 2.0 compatibility mode and behaves the same as BT 2.0. If both devices are BT >/= 2.1, Secure Simple Pairing must be used according to the BT spec.

Security Mode 4: Simple Secure Pairing

Simple Secure Pairing: a new security architecture introduced supported in BT >= 2.1. Service-level enforced, similar to mode 2. Mandatory when both devices are BT >= 2.1. There are four association models currently supported by mode 4. Security requirements for services must be classified as one of the following: authenticated link key required, unauthenticated link key required, or no security required. SSP improves security through the addition of ECDH public key cryptography for protection against passive eavesdropping and man-in-the-middle (MITM) attacks during pairing.

| Numeric Comparison | Just Works |
|--|--|
| Designed for situation where both devices are capable of displaying a six-digit number and allowing user to enter "yes" or "no" response. During pairing, user enters "yes" if number displayed on both devices matches to complete pairing. Differs from the use of PINs in legacy (BT<=2.0) pairing because the number displayed for comparison is not used for subsequent link key generation, so even if it is viewed or captured by an attacker, it could not be used to determine the resulting link or encryption key. | Designed for situation where one (or both) of the pairing devices has neither a display nor keyboard for entering digits (e.g., Bluetooth headset). It performs authentication step 1 in the same manner as as numeric comparison, but the user cannot verify that both values match, so MITM (man-in-the-middle) protection is not provided. This is the only model in SSP that does not provide authenticated link keys. |

Each mode, except for Just Works, has Man-In-The-Middle (MITM) protection, meaning no third device can view the data being passed between the two devices involved. The SSP mode is usually negotiated automatically based on the capabilities of both the master and slave. Lower security modes can be disabled via the bluetooth.minimum_security_mode SGD. The bluetooth.minimum_security_mode SGD sets the lowest security level at which the printer will establish a Bluetooth connection. The printer will always connect at a higher security level if requested by the master device. To change the security mode and security settings in the printers, use Zebra Setup Utilities.

| Set-Get-Do | BT Version of Master Device (>2.1) |
|-----------------------------------|--|
| bluetooth.minimum_security_mode=1 | Secure Simple Pairing Just Works/Numeric Comparison |
| bluetooth.minimum_security_mode=2 | Secure Simple Pairing Just Works/Numeric Comparison |
| bluetooth.minimum_security_mode=3 | Secure Simple Pairing Numeric Comparison |
| bluetooth.minimum_security_mode=4 | Secure Simple Pairing Numeric Comparison |
| bluetooth.bluetooth_PIN | Not Used |

Bluetooth Minimum Security Modes

The ZQ220 printer also features bonding for Bluetooth. The printer caches pairing info so devices stay paired through power cycles and disconnects. This eliminates the need to re-pair on every connection establishment.

The bluetooth.bonding SGD is on by default.

M

Note • For detailed information on Bluetooth, please refer to the Bluetooth Wireless User Guide (P1068791-002) at: <u>http://www.zebra.com/us/en/support-downloads.html</u>

In addition, the printers support a "scan and pair" function via a handheld device and the MAC Address label on the bottom of the printer (see "Figure 8 • BT Communications" on page 33). The ZQ220 printer also features passive Near Field Communication (NFC) technology. Using the "Print Touch" feature located on the side of the printer, end users can automatically pair with a handheld device that supports NFC technology. The NFC tag has the printer's BDADDR encoded in a URL on the tag. Simply touching the NFC handheld device to the "Print Touch" icon on the printer will connect and pair the handheld device to the printer.



Figure 8 • BT Communications

Setting Up the Software

The printer uses Zebra's CPCL Programming language which was designed for mobile printing applications. CPCL is fully described in the CPCL Programming Guide (p/n P1073699-001) available on-line at https://www.zebra.com/manuals. You can also use ZebraDesigner Pro v2, Zebra's Windows[®] based label creation program which uses a graphical interface to create and edit labels in either language. See "Appendix G" on page 62 for tips on downloading the Designer Pro application from Zebra's Web site.

Designing Labels

The following examples provide guidelines for designing labels for the printers, specifically for Gap Media, Black Bar Media and Journal Media. The illustrations for each media type define recommended tolerances, keep-out zones and safe printing zones designed to avoid any vertical registration issues during printing. Dimensions are determined based on product registration capabilities and Zebra-recommended media tolerances.



Figure 9 • Gap Media

Figure 10 • Journal Media







Using Pre-Printed Receipt Media

The ZQ220 printer supports alignment of pre-printed receipts by using the out of paper sensor located near the printhead.

Black Mark Dimensions (Receipt Media)

The reflective media black marks (or black bar/marks) should extend past the centerline of the roll on the front side of the paper.

- Minimum mark width: 0.59 in. (15 mm) perpendicular to the edge of the media, and centered within the width of the roll.
- Mark length: 0.19 0.24 in. (4.8 6.0 mm) parallel to the edge of the media.

Label Areas

The media/black bar sensor detects the dark, pre-printed bar on the media, so a path in the center of the paper must be kept free of dark, pre-printed graphics.

M

Note • Dark, pre-printed graphics refer to any symbols, barcodes, text and/or colored areas that have been applied to the receipt paper rolls before they have ever been used in the printer.





Label Design Examples

This section shows examples of labels with and without problems.



Figure 13 • Label Design Examples

VIOLATION

Ξの ω

ø Ω 4 ო

2 __



Note • Complete information on using pre-printed receipt paper can be found in the FORM command in the CPCL Programming Guide (P1073699-001) at www.zebra.com/manuals.

Keep-Out Areas

At times, incomplete printing of text and/or graphics appear because minimum margins are not provided during label design. The recommended minimum margins, or "keep out areas" are shown in Figure 14.



Figure 14 • Keep Out Areas

Note • The length of each "continuous" receipt is determined by the data sent to the printer.

Near Field Communication (NFC)

RA

Devices using NFC may be *active* or *passive*. A passive device, such as a ZQ220 printer with an NFC tag, contains information that other devices can read but does not read any information itself. An active device, such as a smartphone, can read the information on the printer's NFC tag, but the tag itself does nothing except transmit the info to authorized devices.



NFC Use Cases

- *Bluetooth Pairing* used to cause a tablet, smart phone or terminal to automatically pair with the printer via a Bluetooth connection, within the bounds of the security profile being used. This shall contain the BT address and serial number of the printer.
- *App launching* used to cause an app, developed either by Zebra or a third party to be executed on a smartphone, tablet or terminal
- Web site launching used to cause a smart phone, tablet or terminal to display a web site developed by Zebra or a third party developer



Note • Tapping the Zebra Print Touch[™] icon[™] with a Near Field Communication (NFC) enabled smartphone will provide instant access to printer-specific information. For more information about NFC and Zebra products, go to <u>http://www.zebra.com/nfc</u>. Bluetooth pairing applications via NFC is also possible. Please see Zebra Legacy SDK for more information.

Wearing the Printer

Swivel Belt Clip

The ZQ220 printer has a plastic swivel belt clip included as a standard feature.

To install or remove the belt clip:

- 1. Remove the battery pack.
- 2. Slide the belt into the slot on the bottom of the printer.
- 3. Reinstall the battery pack.

To use the belt clip:

Hook the belt clip over your belt, and ensure that the clip is securely attached to the belt. The belt clip will pivot to allow you to move freely while wearing the printer.



Figure 16 • Printer with Belt Clip

Adjustable Shoulder Strap

Refer to Figure 17 if your printer is equipped with the shoulder strap option (p/n SG-MPV-SDSTP1-01).



- Figure 17 Using the Optional Shoulder Strap
 - 1. Clip one end of the shoulder strap to the post (circled) on the front side of the printer.

2. Clip the opposite end of the strap to the second post (circled) to secure.



3. The printer will hang securely from both clips and the strap can be adjusted to be longer or shorter in length.

Soft Case

The ZQ220 printer has a soft case option (p/n SG-MPV-SC31-01) that also allows you to carry the printer using the shoulder strap.



Figure 18 • Using the Soft Case

1. Lift up the top flap of the soft case which is secured with Velcro. Insert the printer in the case with the bottom of the printer facing forward in this orientation.



2. Turn the case around to access the LCD display and user controls which are visible through the plastic window. The bottom half of the plastic window can be lifted to access the paper path.



Note • The shoulder strap option can be used with the soft case by securing the ends of the shoulder strap on the two metal rings on the soft case.

Preventive Maintenance

Extending Battery Life

- Never expose the battery to direct sunlight or temperatures over 40° C (104° F) when charging.
- Always use a Zebra charger designed specifically for Lithium-Ion batteries. Use of any other kind of charger may damage the battery.
- · Use the correct media for your printing requirements. An authorized Zebra re-seller can help you determine the optimum media for your application.
- · If you print the same text or graphic on every label, consider using a pre-printed label.
- · Choose the correct print darkness, and print speed for your media.
- Use software handshaking (XON/XOFF) whenever possible.
- · Remove the battery if the printer won't be used for a day or more and you're not performing a maintenance charge.
- · Consider purchasing an extra battery.
- · Remember that any rechargeable battery will lose its ability to maintain a charge over time. It can only be recharged a finite number of times before it must be replaced. Always dispose of batteries properly. Refer to "Appendix F" on page 61 for more information on battery disposal.

General Cleaning Instructions

Caution • Avoid possible personal injury or damage to the printer. Never insert any pointed or sharp objects into the printer. Always turn off the printer before performing any cleaning procedures. Use care when working near the tear bars as the edges are very sharp.

Warning • The printhead can get very hot after prolonged printing. Allow it to cool off before attempting any cleaning procedures.



Only use a Zebra cleaning pen (not supplied with the printer) or a cotton swab with 90% medical grade alcohol for cleaning the printhead.



Caution • Use only cleaning agents specified in the following tables. Zebra Technologies Corporation will not be responsible for damage caused by any other cleaning materials used on this printer.

Cleaning

| Area | Method | Interval |
|--|---|--|
| Printhead | Use a Zebra cleaning pen to swab the thin gray line on the printhead, cleaning the print elements from the center to the outside edges of the printhead. | After every five rolls of media (or more often, if needed). When using linerless type media, cleaning is required after every roll of media. |
| Platen Surface (Linered) | Rotate the platen roller and clean it thoroughly with a fiber-free swab, or lint free, clean, damp cloth lightly moistened with medical grade alcohol (90% pure or better) (Figure 19). | After every five rolls of media (or more often, if needed) |
| Platen Surface (Linerless) | Rotate platen roller and clean with a fiber-free swab and 1 part liquid soap (Palmolive or Dawn) and 25 parts water. Use pure water to clean after soap/water mixture. (Figure 20) | Clean platen only if there is an issue during printing, i.e., media not releasing from the platen. (*See Note below.) |
| Scraper (Linerless Units Only) | Use adhesive side of media to clean scraper on linerless units. (Figure 20) | After every five rolls of media (or more often, if needed). |
| Tear Bar | Clean thoroughly with 90% medical grade alcohol and a cotton swab. (Figure 19) | As needed |
| Printer Exterior | Water-dampened cloth or 90% medical grade alcohol wipe. | As needed |
| Printer Interior | Gently brush out printer. Ensure the Backside Sensor and Frontside Sensor windows are free of dust. (Figure 19) | As needed |
| Interior of units with Linerless Platens | Clean thoroughly with 90% medical grade alcohol and a fiber-free swab. (See Figure 20 for specific target areas for interior cleaning.) | After every five rolls of media (or more often, if needed). |



Note • This is an emergency procedure only to remove foreign contaminates (oils, dirt) from the platen that can damage the printhead or other printer components. This procedure will shorten or even exhaust the linerless platen's useable life. If the linerless media continues to jam after cleaning and feeding 1 to 2 meters (3 to 5 feet) of media, replace the platen.



LCD Control Panel Indicators

The printer's display shows several icons which indicate the status of various printer functions (See "Information Screen" on page 25). Check the indicator status, then refer to the Troubleshooting topic referenced in the chart to resolve the problem.

Troubleshooting Topics

- 1. No power:
 - · Check that battery is installed properly.
 - Recharge or replace battery as necessary.

Caution • Always dispose of batteries properly. Refer to "Appendix F" on page 61 for more information on proper battery disposal.

2. Media does not feed:

- Be sure media cover is closed and latched.
- · Check media compartment for any binding.
- Ensure most recently printed label is removed (only in peel mode).
- Ensure label sensor is not blocked.

3. Poor or faded print:

- Clean printhead.
- · Check quality of media.

4. Partial or missing print:

- Check media alignment.
- · Clean print head.
- Ensure media cover is properly closed and latched.
- 5. Garbled print:
 - · Check baud rate.

6. No print:

- Check baud rate.
- Replace battery.
- Check cable to terminal.
- Invalid label format or command structure. Place printer in Communications Diagnostic (Hex Dump) Mode to diagnose problem.

- 7. Reduced battery charge life:
 - If battery is older than one year, short charge life may be due to normal aging.
 - · Check battery health.
 - Replace battery.
- 8. 🖻 displayed:
 - Data icon is normal while data is being received.
- 9. 💩 or 🖬 displayed:
 - Check that media is loaded and that the media cover is closed and securely latched.
- 10. Communication error:
 - · Check baud rate.
 - Replace cable to terminal.
- 11. Label jam:
 - Open head release latch and media cover.
 - Remove and reinstall media.
- 12. Skip Labels:
 - · Check media for top of form sense mark or label gap.
 - Check that the maximum print field has not been exceeded on label.
 - Ensure bar or gap sensor is not blocked or malfunctioning.
- 13. Blank LCD screen:
 - Make sure printer is turned on.
 - No application loaded or application corrupted: reload program.

14. No NFC Connectivity

• Ensure smartphone is positioned 3 inches (7.62 cm) or closer to the Print Touch icon on the side of the printer.

Troubleshooting Tests

Printing a Configuration Label

To print out a listing of the printer's current configuration, follow these steps:

- 1. Turn the printer off. Load the media compartment with journal media (media with no black bars printed on the back).
- 2. Press and hold the Feed Button.
- 3. Press and release the Power button and keep the Feed button pressed. When printing starts, release the Feed button.



Note • The configuration report can also be pressing the Configuration button and navigating to SETTINGS>PRINT.

Refer to "Figure 21 • Configuration Label" on page 50 for sample configuration printouts.

Communications Diagnostics

If there is a problem transferring data between the computer and the printer, try putting the printer in the Communications Diagnostics Mode (also referred to as the "DUMP" mode). The printer will print the ASCII characters and their text representation (or the period '.', if not a printable character) for any data received from the host computer.

To enter Communications Diagnostics Mode:

- 1. Print a configuration label as described above.
- 2. At the end of the diagnostics report, the printer will print: "Press FEED key to enter DUMP mode".
- 3. Press the FEED key. The printer will print: "Entering DUMP mode".



Note • If the FEED key is not pressed within 3 seconds, the printer will print "DUMP mode not entered" and will resume normal operation.

4. At this point, the printer is in DUMP mode and will print the ASCII hex codes of any data sent to it, and their text representation (or "." if not a printable character).

Additionally, a file with a ".dmp" extension containing the ASCII information will be created and stored in the printer's memory. It can be viewed, "cloned" or deleted using the ZebraNet Bridge application. (Refer to the ZebraNet Bridge Enterprise documentation for more information.)

To terminate the Communications Diagnostics Mode and re-turn the printer to normal operations:

- 1. Turn the printer OFF.
- 2. Wait 5 seconds.
- 3. Turn the printer ON.

Contacting Technical Support

If the printer fails to print the configuration label, or you encounter problems not covered in the Troubleshooting Guide, contact Zebra Technical Support. Technical Support addresses and phone numbers for your area can be found in "Appendix H" on page 64 of this manual.

You will need to supply the following information:

- Model number and type (e.g., ZQ220)
- Unit serial number (Found on the large label on the back of the printer, also found in the configuration label printout.)
- Product Configuration Code (PCC) (15 digit number found on the label on the back of the unit)





Specifications



Note • Printer specifications are subject to change without notice.

Printing Specifications

| Parameter | ZQ220 |
|---|--|
| Print Width | Up to 72 mm (2.91 in.) |
| Print Speed | 63.5 mm (2.5 in.)/second |
| Printhead Burn Line to Tear Edge Distance | 4.8 mm (0.19 in.) |
| Printhead Life | 390K inches of paper feed MTBF when using Zebra media. |
| Print Density | 203 dots/in. or better |

Memory and Communications Specifications

| Parameter | ZQ220 |
|----------------------------|--|
| Flash Memory | 16 MB ¹ |
| SDRAM Memory | 16 MB ¹ |
| Wireless Communications | Embedded Dual Mode Bluetooth 2.1+EDR/4.1 Low Energy with integrated antenna and modular certification |

1. Memory configuration on your printer may be ascertained by printing a configuration label as detailed on "Printing a Configuration Label" on page 48.

Label Specifications

| Parameter | ZQ220 |
|---|---|
| Media Width | Standard:80 mm +/- 0.75 mm (3.15 in. +/- 0.02 in.) *Optional: 76.2 mm +/- 0.65 mm (3 in. +/- 0.025 in.) *Optional: 58 mm +/- 0.65 mm (2.28 in. +/- 0.025 in.) *Optional: 50.8 mm +/- 0.65 mm (2 in. +/- 0.025 in.) |
| Min/Max Label Length | 12.5 mm (0.5 in.) minimum (Unconstrained max length in line print mode) |
| Black Bar Sensor to Printhead Burnline Distance | 16 mm (0.63 in.) +/- 0.635 mm (0.025 in.) |
| Media Thickness (except Tag) | 0.058 to 0.1575 mm (2.28 to 6.2 mils) |
| Max Tag Thickness | 0.1397 mm (5.5 mils) |
| Max Label Roll Outer Diameter | 50 mm (1.97 in.) |
| Inner Core Diameters | Media 3.5 mm or less: 12.7 mm (0.5 in.) Media > 3.5 mm: 22.2 mm (0.875 in.) |
| Black Mark Location | The reflective media black marks should be centered on media roll |
| Black Mark Dimensions | Minimum mark width: 12.7 mm (0.5 in.) Mark length: 2.4-11 mm (0.09 to 0.43 in.) |



Note • Use Zebra brand direct thermal media that is outside wound. Media may be reflective (black mark) sensing, or transmissive (gap) sensing, die-cut, continuous or linerless. For die-cut labels, use only full auto dies.

* Optional media requires the use of spacers (KIT-MPV-MD3SPR1-5).

Physical, Environmental and Electrical Specifications

| Parameter | ZQ220 |
|--|---|
| Weight w/ battery | 1.0 lbs. (0.45 kg) |
| | Operating: -10 °C to 50 °C (14 °F to 122 °F) |
| Temperature | Storage: -20 °C to 60 °C (-4 °F to 140 °F) |
| | Charging: 0 °C to 40°C (32 °F to 104 °F) |
| Relative Humidity | Operating/Storage: 10% to 90% non-condensing |
| Battery | 2-Cell Battery Lithium-Ion, 7.26 VDC (nominal); |
| Intrusion Protection (IP) Rating | IP43 (without optional environmental case) |

CPCL Font and Bar Code Specifications and Commands

| Standard Fonts | SWIS721.CSF - CPCL scalable font; DEJAVU12.CPF - Pre- Scaled fonts; DEJAVU14.CPF - Pre-Scaled fonts; DEJAVU16. CPF - Pre-Scaled fonts; DEJAVU20.CPF - Pre-Scaled fonts; English/Latin9 built in EZ320; MUTOS16.CPF - Utah, Vietnamese, 16x16 bitmap; CTUNMK24.CPF - M Kai; Traditional Chinese, 24x24 bitmap; NSMTTC16.CPF - New Sans MT; Traditional Chinese, 16x16 bitmap. Optional International character sets: Chinese 16 x 16 (trad), 16 x 16 (simplified) 24 x 24 (simplified); Japanese 16 x 16 24 x 24 | | | |
|-------------------------------|---|--|--|--|
| Available Optional Fonts | Optional Interna x 16 (simplified) | tional character sets: Chinese 16 x 16 (trad), 16 ,24 x 24 (simplified); Japanese 16 x 16, 24 x 24 | | |
| Linear Bar Codes Available | Codabar (CODA UCC/EAN 128 (Code 39 (39, 39 Code 93 (93) Code 128 (128) EAN 8, 13, 2 an EAN13, EAN13; EAN-8 Composi EAN-13 Composi EAN-13 Compo Plessey (PLESS Interleaved 2 of MSI (MSI, MSI1 FIM/POSTNET TLC39 (TLC39) UCC Composite UPCA, 2 and 5 UPCA Composi UPCE, 2 and 5 | Barcode (CPCL Command) ABAR, CODABAR 16) UCCEAN128) 9C, F39, F39C) d 5 digit extensions (EAN8, EAN82, EAN85, 2, and EAN135) ite (EAN8) site (EAN13) SEY) 5 (I2OF5) 0, MSI1110) (FIM) e A/B/C (128(Auto)) digit extensions (UPCA2 and UPCA5) te (UPCA) digit extensions (UPCE2 and UPCE5) te (UPCE) | | |
| 2-D Bar Codes Available | RSS: | Aztec (AZTEC) MaxiCode (MAXICODE) PDF 417 (PDF-417) QR Code (QR) RSS-14 (RSS-Subtype 1) RSS-14 Truncated (RSS-Subtype 2) RSS-14 Stacked (RSS-Subtype 3) RSS-14 Stacked Omnidirectional (RSS-Subtype 4) RSS Limited (RSS-Subtype 5) RSS Expanded (RSS-Subtype 6) | | |
| Rotation Angles | 0°, 90°, 180°, ar | nd 270° | | |



Figure 22 • Printer Dimensions

Printer Accessories

| Region | Part # | Description |
|--------|---------------------|---|
| NALA | PWR-WUA5V12W0US | AC to USB Adaptor; ZQ3 (US) |
| EU | PWR-WUA5V12W0GB | AC to USB Adaptor; ZQ3 (UK) |
| EU | PWR-WUA5V12W0EU | AC to USB Adaptor; ZQ3 (EU) |
| LA | PWR-WUA5V12W0BR | AC to USB Adaptor; ZQ3 (BR) |
| AP | PWR-WUA5V12W0IN | AC to USB Adaptor; ZQ3 (IN) |
| AP | PWR-WUA5V12W0KR | AC to USB Adaptor; ZQ3 (KR) |
| WW | CHG-AUTO-USB1-01 | Cigarette to USB Adapter; ZQ3 |
| WW | BTRY-MPV-24MA1-01 | Spare 2450 mAh battery for ZQ220/ZQ120 |
| WW | KIT-MPV-MD3SPR1-5 | Spacers for ZR138/ZQ120/ZQ220 media compartment to accept 3" (76.2), 2.3"(58) and 2" (50.8) wide paper, (5 sets; 2 per set) |
| WW | SG-MPV-SC31-01 | Soft Case ZR138/ZQ120/ZQ220 |
| WW | SG-MPV-SDSTP1-01 | Shoulder Strap ZQ220/ZQ120/ZR138 |
| WW | KIT-MPM-BLTCLP5-01 | Belt Clip for ZQ300 Series, Qty. 5 |
| NA | SAC-MPP-3BCHGUS1-01 | 3-slot Battery Charger, ZQ6/ZQ5 (US) |
| EU | SAC-MPP-3BCHGEU1-01 | 3-slot Battery Charger, ZQ6/ZQ5 (EU) |
| EU | SAC-MPP-3BCHGUK1-01 | 3-slot Battery Charger, ZQ6/ZQ5 (UK) |
| LA | SAC-MPP-3BCHGBR1-01 | 3-slot Battery Charger, ZQ6/ZQ5 (BR) |
| AP | SAC-MPP-3BCHGAU1-01 | 3-slot Battery Charger, ZQ6/ZQ5 (AU) |
| AP | SAC-MPP-3BCHGCN1-01 | 3-slot Battery Charger, ZQ6/ZQ5 (CN) |
| AP | SAC-MPP-3BCHGIN1-01 | 3-slot Battery Charger, ZQ6/ZQ5 (IN) |
| WW | CBL-MPV-USB1-01 | USB Cable (Type A to Type C), ZQ220 QTY1 |
| WW | CBL-MPV-USB1-05 | USB Cable (Type A to Type C), ZQ220 QTY5 |



Note • For more information on Zebra accessories, go to

https://www.zebra.com/us/en/products/accessories/printer-print-engine.html.



Note • Refer to "Appendix A" on page 57 for additional information on Data I/O cables.



Note • The 3-slot battery charger can only be used after firmware modifications have been made to the charger.

USB Cables

Part Numbers P1081545; ASSY,CABLE,USB A TO C





A4, B4, A9, B9 -

| Туре-С | C Plug | ١ | Vire | Туј | oe-A Plug |
|-------------------|----------------|------------|----------------|----------|----------------|
| Pin # | Signal Name | Wire # | Signal Name | Pin # | Signal Name |
| A1,B1, A12,B12 | GND | 1 | GND_PWrt1 | 4 | GND |
| A4,B4,A9, B9 | VBUS | 2 | PWR_VBUS1 | 1 | VBUS |
| A5 | СС | See Note 1 | | | |
| B5 | VCONN | | | - | |
| A6 | Dp1 | 3 | UTP_Dp | 3 | D+ |
| A7 | Dn1 | 4 | UTP_Dn | 2 | D- |
| | Shield | Braid | Shield | Shell | Shield |

Notes:

- 1. Pin A5 (CC) of the USB Type-C plug shall be connected to VBUS through resistor Rp (56 k Ω +/- 5%).
- 2. Contacts B6 and B7 should not be present in the USB Type-C plug.
- 3. All VBUS pins shall be connected together within the USB Type-C plug. Bypass capacitors are not required for the VBUS pins in this cable.
- 4. All ground return pins shall be connected together within the USB Tupe-C plug.
- 5. Shield and GND grounds shall be connected within the USB Type-C and USB 2.0 Standard-A plugs on both ends of the cable assembly.
- 6. All UsB Type-C plug pins that are not listed in this table shall be open (not connected).

Appendix B

Media Supplies

To insure maximum printer life and consistent print quality and performance for your individual application, it is recommended that only media produced by Zebra be used.

Advantages include:

- Consistent quality and reliability of media products.
- · Large range of stocked and standard formats.
- In-house custom format design service.
- Large production capacity which services the needs of many large and small media consumers including major retail chains world wide.
- Media products that meet or exceed industry standards.

For more information go the Zebra website (<u>www.zebra.com</u>) and select the Products tab.

Appendix C

Maintenance Supplies

In addition to using quality media provided by Zebra, it is recommended that the printer be cleaned as prescribed in "Cleaning" on page 44. The following item is available for this purpose:

• Cleaning Pen (12 pack): p/n 105950-035

Appendix D

Serial and PCC Number Locations



0

Important • Due to compliance and customs restraints, an integrator may not be able to ship a printer purchased in one country to another country based on the limitations imposed by regional SKUs. The country code identified in the printer SKU determines the area of the world in which the printer can be used.

Appendix E

Battery Disposal



The EPA certified RBRC[®] Battery Recycling Seal on the Lithium-Ion (Li-Ion) battery supplied with your printer indicates Zebra Technologies Corporation is voluntarily participating in an industry program to collect and recycle these batteries at the end of their useful life, when taken

out of service in the United States or Canada. The RBRC program provides a convenient alternative to placing used Li-Ion batteries into the trash or the municipal waste stream, which may be illegal in your area.



Important • When the battery is depleted, insulate the terminals with tape before disposal.

Please call 1-800-8-BATTERY for information on Li-Ion battery recycling and disposal bans/restrictions in your area.

Zebra Technologies Corporation's involvement in this program is part of our commitment to preserving our environment and conserving our natural resources.

Outside North America, please follow local battery recycling guidelines.

Product Disposal



The majority of this printer's components are recyclable. Do not dispose of any printer components in unsorted municipal waste. Please dispose of the battery according to your local regulations, and recycle the other printer components accordingto your local standards.

For more information, please see our web site at: <u>http://www.zebra.com/environment.</u>

Alert Messages

The printers will display the following alert messages on the Information Screen to inform the user of various performance conditions that might occur with the ZQ220.

| Event | Туре | English Phrase |
|---------------------|---|------------------|
| Download Firmware | User Activity | Download FW |
| Download Failed | User Activity | Download Failed |
| BT Pairing PIN | Timed – 30 seconds. Configuration button accepts pairing pin. If timeout expires, go to BT Pairing Failed Alert. | Pairing: 123456 |
| BT Pairing Ongoing | User Activity | Pairing Ongoing |
| BT Pairing Accepted | Timed – 5 seconds | Pairing Accepted |
| BT Pairing Rejected | Timed – 5 seconds | Pairing Rejected |
| BT Pairing Failed | Timed – 5 seconds | Pairing Failed |
| BT Pairing Success | Timed – 5 seconds | Pairing Success |
| Head Over temp | User Activity | Head Overtemp |
| Head Under temp | User Activity | Head Undertemp |
| Battery Too Low | User Activity | Battery Too Low |
| Media Out | User Activity | Media Out |
| Head Open | User Activity | Head Open |
| Charge Error | User Activity | Charge Error |
| Battery Missing | User Activity | No Printing |
| Battery Low | User Activity | Battery Low |
| Printer Ready | Timed – 30 seconds | Printer Ready |

Appendix G

Using Zebra.com

The following examples illustrate the search function on Zebra's website for finding specific documents and downloads.

Example 1: Finding the User Guide.

Go to http://www.zebra.com/us/en/support-downloads.html

Type the appropriate printer name in search box.

| Support and Downloads | WNLOADS | | | | |
|-----------------------------|---|---|-------------------|-------------------------|-----------|
| | BROWS | SE BY PRODUCT vare, drivers, utilities, software and k | TYPE | | |
| Mobile Computers Tablets | Printers Interactive Klosks Enter yr 20220 | Barcode Scanners Software - OR - our Product Name or Model N | OEM Wristbands | Type Prir (i.e., ZQ2 | nter Name |
| | ZEBRA DESIGNER PRINTER-SOFTWARE | LABEL DESIGN SOFTWAF | RE > | - | |

Click on "Manuals" tab on the printer main page.

| Expert of Southern S Finder S for the Southern S | Inter Suspent IPPORT In addition to the printer support and repair resources on this page, also see the following: Specifications Search Printer Accessories Printer Parts Supply Selector Product readmention in observe reconsult. |
|--|--|
| How-To Videos Drivers Firmware | Product Info Fo: Z0220> Culck Troublesheating Guide v Print DNA Software > Software Developer Tools Manuals Knowledge Articles |
| Legend: | 🛨 Unrestricted 🔔 DemoWare |
| | |
| | |
| | |

Click on the dropdown menu to choose your language, and then click on the download button next to the selected manual.

| Download 8 |
|------------|
| |
| Download 1 |
| |
| Download 7 |
| |
| Download 5 |
| n |
| m |
| |
| |
| |
| |
| |
| |
| |

Product Support

To contact product support in your region, go to: <u>https://www.zebra.com/contact</u>.

When calling with a specific problem regarding your printer, please have the following information on hand:

- Model number/type (e.g., ZQ220).
- Unit serial number.
- Product Configuration Code (PCC) (refer to "Appendix E" on page 60)

Index

Α

Accessories 40–65, 56 Appendix A, USB Cables 58 Appendix B, Media Supplies 59 Appendix C, Maintenance Supplies 59 Appendix D, Parameters Menus 60 Appendix E, Battery Disposal 61 Appendix F, Alert Messages 62 Appendix G, Using Zebra.com 63 Appendix H, Product Support 65

В

Battery, installing 15 Battery pack Power Precision 10 Battery Safety 18 Belt Clip 40 Black Mark Dimensions 35 Bluetooth 30 Bluetooth, minimum security modes 32 Bluetooth, networking 30 Bluetooth, security modes 31

С

Cable Communication 29 Charger, battery 18–65 Charger Safety 18 Communications Diagnostics 48 Configuration Label, sample 50 CPCL Font and Bar Code Specifications and Commands 54

D

Designing Labels 34 Dimensions, ZQ220 55 Document Conventions 7

G

General Cleaning Instructions 43

Getting Ready to Print 15

Н

Home Menu Screen 26

I

Installing the Battery 15 Introduction to the ZQ220 Printers 8

L

Label Areas 36 Label Design Examples 37 LCD Control Panel 24, 46

Μ

Made for iPhone (MFi) 12 Media, loading 21

Ν

Near Field Communication (NFC) 12, 38

Ρ

Power-Up Sequences 27 Preventive Maintenance 43 Printer Status Icons 25 Printing Method Direct Thermal 11 Programming language CPCL 8

Q

QR Code 11

S

Shoulder Strap 41 Smart Battery, PowerPrecision+ 10 Smart Charger-2 (SC2) Single Battery Charger 21 Soft Case 42 Specifications, label 53 Specifications, memory and communications 52 Specifications, physical, environmental and electrical 55

65

Specifications, printing 52 Status Bar Icons 25

Т

Troubleshooting, tests 48 Troubleshooting, topics 46

V

Verify printer is working 27

W

Wearing the Printer 40

Ζ

Zebra Setup Utilities 30 ZPL Font and Bar Code Specifications and Commands 55 ZQ220 Accessories 56



Zebra Technologies Corporation 3 Overlook Point Linconshire, IL 60069 USA P: +1 847.634.6700 or F: +1 847.913.8766